

► COIN PAYMENT SYSTEM

Basic self-service payment system for laundromats which is easy to use for both customers and owners.

This payment system consists of change machine where the user can exchange bills for coins or tokens and coin box where the client inserts coins or tokens and thereby enables a washing or drying cycle.

Possible connection to the fiscalization system.

CHANGE MACHINE BW EASY COIN



- The money changer is intended for changing bills into coins or tokens.
- Capacity of coins 1000 pcs
- The gearbox has the ability to eject one type of tokens / coins.
- It is possible to mount it on the wall or on free-standing stand (purchased separately)

BW COIN BOX WITH MECHANISM BW EMP 500 DOUBLE



- Coin boxes are used for payment via coins or tokens.
- Works on local currency or tokens (jetons)
- Stainless steel casing with door for collecting coins / tokens
- Can be used for one machine (single) or for the tower/two machines (double)
- Laser coin reader"



JETONS - 50/1 PCS BW JETON 11 MS


- Metal jetons
- Specially designed for BW coin boxes

PAYMENT SYSTEMS FOR LAUNDROMATS ARE IDEAL FOR SELF-SERVICE LAUNDRIES, CAMPS, AND MARINAS, STUDENT DORMITORIES, ACCOMMODATION FACILITIES FOR WORKERS, ETC., EVERYWHERE IT IS DESIRED TO HAVE WASHING AND DRYING SERVICES DONE BY THE USERS THEMSELVES

► CASHLESS (CARD& PREPAID) PAYMENT SYSTEMS

More advanced payment systems that offer the option of paying with bank cards, mobile payment, via QR code or with prepaid cards or keys. An option for anyone who wants a cashless payment available.

CARD PAYMENT TERMINAL NAY BW001



- Terminal with support for cashless payment up to 6 devices
- Touch screen with integrated camera
- One device that accepts all types of cashless payment in real time:
 - Credit and debit cards
 - Mobile and NFC payment
 - Prepaid cards
 - QR payment code
- It is mounted on the wall of the laundry room

PREPAID PAYMENT TERMINAL EUR NEXT



- Payment system with prepaid cards or prepaid keys
- Payment is made by inserting a card or key into the reader.
- Recharging cards or keys via countertop recharge box
- Mounted directly on the device (washing machine or dryer)"



Countertop
recharge box